Touch screen

By touching the screen with your finger, you can control the audio system and air conditioning system, and adjust the screen display, etc.

Button	Page
"CLIMATE"	P. 331
"AUDIO"	Navigation System Owner's Manual
"SETUP"	P. 329/ Navigation System Owner's Manual
"DISP"	Navigation System Owner's Manual
"MAP/VOICE"	Navigation System Owner's Manual
"DEST"	Navigation System Owner's Manual
"INFO/PHONE"	P. 330/ Navigation System Owner's Manual

Set up screen

You can change the touch screen to your desired settings.

Press “SETUP” to display the “Setup” screen.

Switch	Page
“General”	Navigation System Owner's Manual
“Clock”	Navigation System Owner's Manual
“Voice”	Navigation System Owner's Manual
“Navi.”	Navigation System Owner's Manual
“Phone”	Navigation System Owner's Manual
“Audio”	Navigation System Owner's Manual
“Vehicle”	P. 245/ Navigation System Owner's Manual
“Other”	Navigation System Owner's Manual

Information screen

"Information" screen can be used to display the fuel consumption information or operate the hands-free system.

Press "INFO/PHONE" to display the "Information" screen.

Switch	Page
"Phone"	Navigation System Owner's Manual
"Fuel Consumption"	P. 39
"MAP Data"	Navigation System Owner's Manual
"Calendar"	Navigation System Owner's Manual
"LEXUS Insider"	Navigation System Owner's Manual
"XM Sports"	Navigation System Owner's Manual
"XM Stocks"	Navigation System Owner's Manual
"XM Nav Weather^{TM}"	Navigation System Owner's Manual